


OPERATION, MAINTENANCE AND SPARE PARTS MANUAL

CHIPPER **CH 160** **CH 160T i=2,1**



**READ THIS OPERATION AND MAINTENANCE MANUAL CAREFULLY
BEFORE USING THE MACHINE**

FARMI®
Forest

Farmi Forest Corporation
Ahmolantie 6
FIN-74510 Iisalmi, Finland
Tel. +358 (0)17 83 241
Fax. +358 (0)17 8324 372
www.farmiforest.fi

WARNINGSYMBOLS IN THIS MANUAL



- **imminent danger which could cause serious personal injury or death**



- **danger which could cause personal injury**



- **conditions or misuse that could damage equipment or machinery**

NOTE!

- **reminders, such as for performing checks or carrying out maintenance or repair procedures**

INTRODUCTION

This manual includes the information and maintenance instructions required for operating the machine in the optimal manner.

Although you have experience in using this kind of machinery, read the operation and maintenance instructions carefully since they include information enabling efficient and safe operation. Regular maintenance is the best way to guarantee the efficient and economical performance of the machine.



Each and every operator must read, understand, and follow all safety instructions and procedures.

CUSTOMER FEEDBACK

We are happy to receive your opinions and suggestions for improvements by mail, fax or e-mail. All implemented suggestions for improvements will be rewarded.

CH160



MANUFACTURER'S DECLARATION OF CONFORMITY

Farmi Forest Corporation
Ahmolantie 6, FIN-74510 IISALMI, Finland

Informs that the machine, launched on to the market

Farmi Chipper
(make)

CH160 / CH160T
(type)


(serial number)

conforms to the directives 98/37/EC and 89/336/EC, as amended, and the national regulations bringing these directives into force.

In designing the machine, the following unified standards have been applied:

EN 12100-1/2, EN 982, EN 60201-1




| | |
|-------------------|------------|
| Iisalmi , Finland | 15.11.2007 |
| (place) | (date) |


Juhana Hallivuori

CH160

TABLE OF CONTENTS

| | |
|---------------------------------------------|----|
| SAFETY INSTRUCTIONS | 5 |
| STICKERS AND PLATES | 8 |
| PRESENTATION | 10 |
| LIFTING | 12 |
| ASSEMBLY INSTRUCTIONS | 12 |
| SHORTENING THE PTO SHAFT | 13 |
| MOUNTING ON THE WILLE 445 ADAPTER | 14 |
| MOUNTING ON THE BOBCAT ADAPTER | 15 |
| INSTALLING THE HD 100 | 16 |
| INSTALLING THE 160T i=2.1 BELT TRANSMISSION | 17 |
| OPERATING THE CHIPPER | 18 |
| STOPPING A TRACTOR-DRIVEN CHIPPER | 18 |
| PERIODIC MAINTENANCE | 20 |
| KNIFE AND ANVIL MAINTENANCE | 21 |
| REPLACING THE SPLINED SHAFT | 24 |
| REPLACING THE BEARING | 25 |
| ADJUSTING THE BEARING CLEARANCE | 26 |
| SPARE PARTS | 27 |
| DISCHARGE PIPE | 27 |
| CH160 | 28 |
| BELT TRANSMISSION CH160T i=2,1 | 30 |
| BEARING SYSTEM | 32 |
| MOUNTING FRAME | 33 |
| FEED CHUTE F160 | 34 |
| LÖSI EPMS 100 C | 36 |
| HD100 | 38 |
| ADAPTER WILLE | 39 |
| ADAPTER BOBCAT | 40 |

|  Thread |  Millimeter |  Inch |
|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| M6 | 10 | 7/16 |
| M8 | 13 | 1/2 |
| M10 | 17 | 11/16 |
| M12 | 19 | 3/4 |
| M16 | 24 | 15/16 |
| M20 | 30 | 1 3/16 |
| M24 | 34 | 1 7/16 |

When ordering spare parts, please indicate machines type from the machine plate, spare parts order number, description and quantity required.

Example. CH160, knife, 43510220, 2 pc

SAFETY INSTRUCTIONS

These safety instructions are meant for the owners of FARMI equipment, as well as those who operate, service or repair it.

The instructions help with:

- using the machine safely, appropriately and effectively.
- identifying, avoiding and preventing potentially dangerous situations.

The manufacturer supplies an instruction manual, which must always be available at the place of operation of the machine. Each user must read the safety, maintenance and operating instructions before operating the machine, and comply with these instructions at all times.

Ensure that every operator of the machine is familiar with the content of the instruction manual and situation-specific safety instructions, and has been suitably trained before operating the machine.

The machine complies with technical requirements and applicable safety regulations. However, incorrect use, maintenance or repair of the machine may cause risks.

In addition to the instruction manual, remember to comply with regulations of the local occupational health and safety authorities, and with your country's laws and decrees.

The manufacturer is not liable for damages caused by:

- incorrect, negligent or inappropriate use of the product.
- non-original spare parts.
- normal wear and tear.
- misuse caused by an untrained person's improper actions.
- alterations made without the manufacturer's permission.



Written authorization must be requested from the manufacturer for any alterations to the machine.

STARTING

- Familiarize yourself thoroughly with the use, operation and controls of the machine and its equipment before starting.
- Familiarize yourself with the capacities and limitations of the machine and its equipment.
- Do not use the machine unless you are completely familiar with its operation.
- Be aware of the machine's danger zones.
- During operation, prevent bystanders from entering the danger zone.
- Ensure that each operator has the necessary safety equipment, such as a helmet, safety goggles, work safety boots and suitable protective clothing.
- Never wear loose clothing around moving parts. Protect long hair!
- Ensure that work is carried out according to the stipulations of applicable occupational health and safety legislation.
- Before starting up or using the machine, ensure that it cannot cause a risk to other people or property.
- Perform a safety check on the machine before every use. If you observe any faults or deficiencies, repair the machine immediately.
- Before operating the machine, ensure that there are no foreign articles in it.
- Place the machine on a hard, level surface for operation. In the winter avoid working in slippery areas.
- Before operation, ensure the machine is properly connected.
- Never use a faulty or deficient machine.

OPERATION



Many occupational accidents take place in abnormal circumstances. Therefore it is important to take into account all the possible circumstances that may arise during operation of the machine.

- Depending on the machine's type, it will have diverse safety devices and protectors. These are meant to protect the machine and its operator, and they must never be removed or altered. Never start up or use the machine without all the safety devices and protectors in place. Also check the universal joint's safety equipment and joints.
- Never insert any body part into the machine with the engine running.
- If any faults arise that may jeopardize occupational safety, turn off the machine.
- During operation, the machine's operator is responsible for safety in the whole work area. Work may not be carried out in the presence of any factors that jeopardize occupational safety.
- Exercise extreme caution when hitching / unhitching the machine from a tractor/trailer.



The machine's operator must have constant, unobstructed visibility of the work area. If this is not possible, the operator must work with an assistant.

- Look out for moving parts when the machine is in operation.
- Secure the machine against unauthorized and accidental operation (e.g. moving when parked) whenever it is left unattended.
- Never leave the machine running unattended.
- Avoid causing fast, stroke-like loading.
- Never exceed the given operating values.
- All safety and warning signs on and in the machine must be legible and intact.
- The machine may not be operated by persons who are unwell or under the influence of drugs or alcohol.

MAINTENANCE

- The machine may only be serviced and repaired by professionals.
- Electrical and hydraulic faults may only be repaired by authorized professionals.
- In cases requiring welding, contact the manufacturer.
- Turn off the tractor engine and disconnect the universal joint before beginning service or maintenance actions.
- Ensure that there is no pressure in the hydraulic system.
- Take out the key from the tractor's ignition for the duration of the servicing or maintenance. Check that the power is off from the machine you are working on.
- When servicing the machine, place it on a level surface and ensure that it cannot be moved.
- Observe the service intervals and annual safety inspections.
- All spare parts and equipment must fulfill the manufacturer's requirements. This can be guaranteed by using original parts.
- Put all safety devices back into place immediately once servicing or maintenance is complete.



When lifting the machine, check that the lifting/hoisting equipment is in perfect working order. Check the weight of the machine before lifting it. Choose lifting trajectories so that they do not cause any danger.

Many countries have specific legislation on lifting, hoisting cables and hoists. Always comply with local safety regulations.

OILS AND LUBRICATION

- Always use the oil types recommended by the manufacturer. Other types of oil may cause faults or improper operation of the equipment, which could lead to serious damage to people or property.
- Never mix different liquids or oils.
- Always follow the manufacturer's lubrication instructions.
- Use control equipment carefully until the hydraulic oil has had time to reach its operating temperature.


SAFETY INSTRUCTIONS FOR HYDRAULIC CIRCUITS

1. Work on hydraulic equipment may only be carried out by professional hydraulic engineers.
2. Be cautious when using the equipment in cold conditions.
3. Check the machine for leaks. Do not use the machine if there is a leak from any system. Check all hydraulic hoses – particularly those which are bent during use – and replace any that are in poor condition or have leaks. Ensure that all joints are tight and that the lines are not damaged. Check that all protective caps and filler caps are closed properly.
4. Check that all hose connectors, lengths and qualities comply with applicable requirements. When replacing or repairing hoses, use original parts or hoses and connectors recommended by the manufacturer. Check particularly that the pressure classes of the hoses and connectors are suitable to the operating pressure levels.
5. Check that all safety devices such as pressure relief valves, etc., are in place and work properly. Familiarize yourself with their use. Safety systems may never be bypassed.
6. Check the main hydraulic parts daily, and always after a fault. Replace any damaged parts immediately.
7. If a component is damaged, clean it before repairing it. Do not use solvents when cleaning parts.
8. Do not attempt to carry out repairs that you are not fully familiar with.
9. Never carry out repairs of the hydraulic circuit when the system is pressurized. When pressurized, the oil spray can penetrate the skin and cause mortal danger.
10. Never work below a device or component that is only being held up by hydraulics. Use separate supports when carrying out maintenance or repairs. Do not disconnect cylinders or their valves until the machine is well supported.
11. Most hydraulic oils do not evaporate easily. Risk factors include hot oil, spills and oil mist (pressurized).
12. If oil gets into your eyes, rinse with plenty of water and contact a doctor.
13. Avoid prolonged or repeated contact with your skin.
14. If sprays or contact with the skin cannot be avoided, use protective gloves, goggles and clothing as necessary. Do not use oily clothing.
15. Avoid discharging hydraulic oil into the environment, as it can pollute waterways and the groundwater. When working in ecologically vulnerable areas, use biofuel.
16. Store the oil in sealed containers provided by the manufacturer. Try to transfer the oil directly from its container into the tank.
17. If the oil must be passed through other containers, ensure that they are completely clean. Caps, funnels, sieves and filling holes must also be clean.
18. Never store oil outdoors, as water could condense in it.
19. Always dispose of oil in a suitable container, never into the environment!

CH160

STICKERS AND PLATES

These plates and stickers must be found on the chipper. Replace missing plates or stickers immediately.



| | | |
|----------------------------------------------|---------------|-----------|
| Farmi Forest Corporation | | |
| Ahmolantie 6 FIN-74510 IISALMI FINLAND | | |
| | | CE |
| TYPE | FARMi CHIPPER | 41012520 |
| MODEL | CH 160 | |
| SERIAL NO. | | |
| YEAR OF MANUFACTURE | 20 | |
| POWER NEEDED | 10-40 | kW |
| WEIGHT HYDR/MANUAL | 330/270 | kg |
| MAX. HYDR. PRESSURE | 175 | bar |
| OIL FLOW NEEDED | 20 | l/min |

1. Machine plate CH160 (41012520)


| | | |
|----------------------------------------------|---------------|-----------|
| Farmi Forest Corporation | | |
| Ahmolantie 6 FIN-74510 IISALMI FINLAND | | |
| | | CE |
| TYPE | FARMi CHIPPER | 41011740 |
| MODEL | CH 160 T | |
| SERIAL NO. | | |
| YEAR OF MANUFACTURE | 20 | |
| POWER NEEDED | 18-40 | kW |
| WEIGHT HYDR/MANUAL | 450/330 | kg |
| MAX. HYDR. PRESSURE | 175 | bar |
| OIL FLOW NEEDED | 20 | l/min |

1. Machine plate CH160T (41011740)



2. Manufacturer sticker (40605214)

CH160



3. Note! (41015500)

Note!

See operation and maintenance manual.

Note!


Stop the engine and remove the PTO shaft for maintenance.

Risk of cutting injury!


Stop the engine and wait until the disk has stopped.



4. Wear hearing protection. (40142080)



5. Lifting point sticker (41014270)



6. Rotation speed sticker (40141160)



7. FARMI sticker (30616171)

CH160

PRESENTATION

The FarmiCH160 is a double-knife disk cutter for chipping wood up to $\varnothing 160$ mm, for processing wood waste from, e.g., the side of jogging tracks or roads, and for other environmental chipping duties. The chipper can be driven by a tractor with a rating of 10–40 kW. The chipper can also be driven by a separate hydraulic motor.

CH160 accessories:

- Single-motor hydraulic feeder or mechanical hopper
- Independent hydraulic unit HD11
- Separate hydraulic motor drive
- “Wille” adapter
- “Bobcat” adapter
- Belt transmission 160T

MAIN COMPONENTS

1. UPPER CHAMBER
2. LOWER CHAMBER
3. DISK
4. KNIFE
5. VERTICAL ANVIL
6. HORIZONTAL ANVIL
7. TWIG BLADE
8. DISCHARGE PIPE
9. LID
10. HYDRAULIC MOTOR (OPTIONAL)
11. BELT TRANSMISSION 160 T (OPTIONAL)




Fig. 1. Main components

CH160

DIMENSIONS




Fig. 2. CH160 dimensional drawing

| TECHNICAL DATA | CH160 |
|--------------------------|---------------------------------------|
| Type | disc chipper |
| Output | 5-20 m ³ /h |
| Chip length | 13 mm |
| Max. wood diameter | 160 mm |
| Power demand | 10-40 kW |
| PTO rpm | 540 tai 1000 rpm |
| Number of knives | 2 pc |
| Power source | tractor or a separate hydraulic motor |
| Mounting | 3-point linkage |
| Chipper weight | CH160 240 kg CH160T 284 kg |
| Disc diameter | 670 mm |
| Disk weight | 100 kg |
| Discharge pipe turning | 360° |
| Opening of upper chamber | to one side |
| Feeder | manual chute or hydraulic feeder |
| Sound pressure level | 102 dB (A) |
| Sound power level | 120 dB (A) |
| CEN/TC144 WG8N16 | |

CH160

LIFTING



Lifting points for each machine are marked with hook symbols.




Fig. 3. CH160 lifting point.




Fig. 4. Mounting the feeder

ASSEMBLY INSTRUCTIONS

1. Attach the feeder to the chipper from the left side with the hinge pin (1) and from the right side with two bolts (M12) (2). Remember to install the securing bolts (M6) (3). See Fig. 4.
2. Attach the discharge pipe to the chipper with two M10 bolts and one M16 bolt.
3. Mount the chipper on the tractor's 3-point hitch.
4. Install the PTO shaft.
5. Check that the length of the PTO shaft is correct for different hitch positions.

SHORTENING THE PTO SHAFT

1. Connect the device to the tractor.
2. Measure the distance between the splined shafts (Distance A)
3. First cut the thicker shaft shield to the correct length (1). Remember to leave at least a 40 mm clearance. Then cut a similar length off the profile tube (2). Shorten the other half of the PTO shaft in the same way. File off the burr.
4. Interconnect the tubes and check that the shaft has been shortened enough by moving the machine gently. Ensure that there is a 40 mm clearance. Also move the machine sideways to check that the shaft moves freely.




Fig. 5. Measure A, when the distance between the splined shafts is at its shortest.




Fig. 6. Shortening the PTO shaft

CH160

MOUNTING ON THE WILLE 445 ADAPTER (Mounting kit 43510500)

- Attach the top link brackets of the adapter and chipper together with M20 pin and nut. (1)
- Attach the grabbers to the chipper's drawbar assy with four bolts (M16) (2).
- The grabbers have three grooves for the drawbar of the drawbar assy. Attach the grooves of the grabbers (3) so that the chipper is as vertical as possible at the operating position.




Fig. 7. Mounting on the Wille 445 adapter

CH160

MOUNTING ON THE BOBCAT ADAPTER (Mounting kit 03510800)

- The mounting assembly replaces the drawbar assy on the chipper frame.
- Attach the mounting plate to the top link brackets of the chipper with M20 pin and nut (1).
- Attach the left and right bracket to the chipper with four bolts (M20) (2).
- Attach the upper beam with four bolts (M12) (3).
- Attach the upper beam to the mounting plate with four bolts (M12) (4).
- Connect the hoses with quick-couplers to the Bobcat. Note the flow directions (see next page).




Fig. 8. Mounting on the Bobcat adapter

CH160

INSTALLING THE HD 100

The chipper can be driven with a separate hydraulic motor coupled to the chipper shaft.

1. Install the motor bracket on the chipper frame as shown in the figure.
2. Attach the coupling sleeve with the keyway facing the hydraulic motor.
3. Attach the hydraulic motor to the motor bracket. Check that the coupling sleeve is on the chipper's splined shaft.
4. Connect the hydraulic hoses to the hydraulics of the drive machine.




Fig. 9. Installing a separate hydraulic motor

CH160

INSTALLING THE 160T $i=2.1$ BELT TRANSMISSION

1. Remove the PTO guard and install to the cover plate (1). Remove the mounting bolts of the small cover plate and remove the cover plate (2) from the mounting frame. These components will not be needed later. See Figure 10.
2. Attach the upper belt pulley assembly (3) and the regulator plate (4) to the chipper with the M12 bolts (5). Tighten the bolts lightly so that the bearing housing can be moved. See Figure 11.
3. Install the belt tightener (6) with the pin (7) and the adjusting assembly with the pin with hole (8). Secure the pins with cotter pins.
4. Install the belts on the upper belt pulley.
5. Push the lower belt pulley (9) onto the splined shaft without the tightening cone (10) while placing the belts into the grooves of the lower belt pulley.
6. Install the lower belt pulley tightening cone, NordLock lock washer pairs, and tightening cone bolts (M12) (11). Tighten lightly so that the lower belt pulley can be moved on the splined shaft.
7. Check the alignment of the belts - see Figure 12. Adjust the alignment of the belt pulleys by moving the upper belt pulley bearing housing and the lower belt pulley.
8. Tighten the bolts of the upper belt pulley bearing housing and the bolts of the lower belt pulley tightening cone (5 and 11) M12 to 80 Nm.
9. Re-check the alignment of the belts and adjust if necessary.
10. Adjust the belt tightener so that the roller touches the belts lightly, then tighten the adjusting bolt (12) by two to three turns. See Figure 13. Be careful not to over-tighten, as this could damage the belts!
11. Attach the plate (1) to the mounting frame with bolts M8 (13).
12. Mount the chipper on the tractor. To check that everything is in order, run the chipper for a while at slow speed.
13. The belts must be run in, first without load for about $\frac{1}{2}$ hour and then with the chipper loaded lightly for the first 8 hours of actual use.
14. Observe the tightness of the belts and, if necessary, adjust with the adjusting bolt (12).




Fig. 10. Removing the covers




Fig. 11. Installing the 160T belt transmission




Fig. 12. Belt alignment




Fig. 13. Installing the 160T belt transmission cover plate

CH160

OPERATING THE CHIPPER

INSPECTIONS PRIOR TO OPERATION

- Park the chipper on level, hard ground.
- Stop the tractor's engine and ensure that the chipper is fully stopped before carrying out the inspections.
- Check that the disk rotates freely by turning the shaft, and ensure that there are no foreign objects inside the chipper.
- Ensure that all protective devices are intact and in place.
Removal of the covers is prohibited.
- Direct the discharge pipe so that flying chips do not pose a risk to the operator or anyone else.



Never disconnect the hydraulics from high rpm. This will cause a risk of cavitation and may damage the hydraulic motor. Check that no sounds

indicating cavitation can be heard from the hydraulic motor.



After stopping the chipper, wait for all movement to stop. The disk continues rotating like a flywheel after the PTO is disengaged.

STARTING THE CHIPPER

- Start the chipper at low tractor engine speed and increase the speed slowly to the required chipping speed (540/1,000 rpm).
- The chipper is now ready for chipping.

STOPPING A TRACTOR-DRIVEN CHIPPER

- Slow the tractor engine speed to idle before disengaging the PTO. This is especially important with tractors featuring a PTO brake (e.g., Ford). Turn the PTO control lever slowly to the OFF position.

STOPPING A HYDRAULIC MOTOR DRIVEN CHIPPER

IMPORTANT! When the chipper is driven by the HD100, it is extremely important to slow the driving engine speed to idle before disconnecting the hydraulics, to prevent cavitation.

CHIPPING

- Before feeding in the material to be chipped, ensure that the wood is free from nails, stones, etc.
- Feed the wood from a standing position on the left side of the feeder.
- Push the wood inside the feed chute until chipping starts. Let go of the wood as soon as the self-feeding starts.
- If you are using a hydraulic feeder, refer to the separate chipping instructions in the feeder manual.



Do not use the chipper in temperatures below -20°C. This is to avoid damage due to brittleness – especially in the knives – caused by the cold. Avoid chipping wood

that is frozen solid, as self-feeding is reduced in this case.

CH160



ROTATING KNIVES!

Knives can cause cutting injury. Do not reach inside the feed chute with hands or feet.



FIRE HAZARD! Always keep adequate fire-fighting equipment on hand when using the chipper. Check the outside temperature of the chipper

regularly. If the chipper heats up abnormally, stop the chipper and determine the cause of the overheating.

Check the temperature of bearings regularly.

Pay special attention to careful maintenance, and keep the chipper free from dust.

If the chipper starts smoking, pour water down the feed chute.

REDUCING THE POWER DEMAND

When using a small tractor to power the CH160 chipper, select a PTO speed of 540 rpm. Run the tractor at full engine speed.

If the tractor's engine speed still decreases during chipping, reduce power demand by altering the chipper to cut with one knife.

The chipper is altered for single-knife operation simply by removing one knife and attaching it to the other side of the disk as a counterbalance, to retain the balance of the disk.

Since the chipper is self-feeding, the feed speed of wood is also halved.




Fig. 14. Remove one knife and attach it to the other side of the disk. The dotted line shows the knife in its normal cutting position.

1. See Sections "Removing the upper chamber" and "Sharpening the knives".
2. Place a spring washer on the bolt. Turn the lock nut on the bolt and tighten to 45 Nm.
3. Place another spring washer on the bolt and turn the bolt through the knife into the disk. See Fig. 14. Tighten the bolts to 45 Nm. Attach the knife using all four bolts.
4. Interchange the cutting and counterbalance knives regularly to ensure the balance of the disk.

CH160

PERIODIC MAINTENANCE



Always disengage the PTO and stop the tractor and chipper fully before maintenance or repair work.

Ensure that the disk is fully stopped before inserting anything inside the feed chute.

Lock the disk before maintenance or repairs.

Park the chipper on hard, level ground to avoid it falling over.

Wear protective gloves when handling knives or anvils.

PERIODIC INSPECTIONS

- With new machines, check the mounting bolts for tightness after the first operating hour, tightening them if necessary. Tightening torques are shown in table.
- Check the mounting bolts for tightness once a week.
- The knife-to-anvil clearance is adjusted to the specified values. For instructions on adjusting the clearance, see Adjusting the knife-to-anvil clearance.




Fig. 15. Checklist for tightening and checking clearances

| Item | Width across flats, mm (inches) | Tightening torque, Nm (lbf) |
|------------------------------------------------------------------|------------------------------------|----------------------------------------|
| 1. Check the knife bolts for tightness. | 17 mm (11/16") | 60 (44 ³ / ₁₆) |
| 2. Check the bearing housing bolts for tightness on both sides.. | 19 mm (3/4") | 80 (58 ¹⁵ / ₁₆) |
| 3. Check the anvil bolts for tightness. | 24 mm (15/16") | 200 (147 ³ / ₈) |
| 4. Check the clearance between knives and vertical anvils. | 19 mm (3/4") | 1,2 - 1,5 mm (0,02 - 0,06") |
| 5. Check the bearings for radial clearance. | | 0,02 - 0,03 mm (0,008 - 0,0012") |

8.1.LUBRICATING THE BEARINGS

- The bearings are lubricated at the factory, and a similar lubricant should be used for subsequent lubrication (Shell Alvania Grease R 3. or Kendall L427). An excessive amount of grease causes overheating and impairs lubrication.
 - Lubricate the bearings every 200 working hours or at least once a year.
- Open the upper bearing housing - see bearing housing assembly drawing, Fig. 28. Remove old grease as carefully as possible and replace it with new grease. Do not fill the bearing housing with grease.
 - Install the upper bearing housing and tighten to 50 Nm.

LUBRICATING THE PTO SHAFT

- Lubricate the PTO shaft prior to operation and regularly, as shown in Fig. 16.
- Lubricate the inner surface of the PTO shaft, accessed via the outer profile tube.
- Lubricate the shield tubes in wintertime to prevent them from freezing and sticking.




Fig. 16. Lubrication points and intervals for the PTO shaft

KNIFE AND ANVIL MAINTENANCE



Read the safety instructions. The disk continues rotating like a flywheel after the PTO is disengaged.



Wear protective gloves when handling knives or anvils.

OPENING AND REMOVING THE UPPER CHAMBER

- Remove the upper chamber (A) securing bolts (M6) (B) and fastening bolts (M12) (C). Turn the upper chamber to the side.
- To remove the upper chamber, remove the securing bolt (M6) (D) and hinge bolt (M12) (E).
- Lock the disk with the lock bolt Fig. 18.
- Remove the feeder or turn it to the side.




Fig. 17. Removing the upper chamber

REMOVING THE KNIVES




Fig. 18. Locking the disk and removing the lock nuts

1. Remove the knife lock nuts (M10). Fig. 18.
2. Remove the knife fastening bolts (M10). Turn the wrench in such a way that your hands would not hit the knife if the wrench should slip. Fig. 19.




Fig. 19. Removing the knife fastening bolts

SHARPENING THE KNIVES



Sharpen all knives equally. This ensures disk balance. Avoid heating the knife during sharpening. Wear protective gloves when handling or anvils.

The knives need sharpening when

- the self-feeding of wood has decreased;
- the power demand has increased;
- the chip surface is rough.

Normally, the knives can be sharpened several times without actually being removed (with, e.g., a sharpening stone or belt grinder).

More thorough conditioning is carried out with a surface grinder, with the knives removed.

The new knives are sharpened to a concave shape, $R=200$. The sharpening angle is 30° and hone angle is 45° . The hone angle prevents the edge from breaking. Fig. 20.




Fig. 20. The profile of a concave knife

It is recommended that the knives be sharpened to a concave shape. If this is not possible, the knife is sharpened to a flat profile. Fig. 21.




Fig. 21. A knife with a flat profile

The hone angle is ground to a 45° angle with two to three longitudinal strokes, using a level sharpening stone.

Burrs are removed from the knife fastening bolt side, grinding with the surface. Fig. 22.




Fig. 22. Final grinding of the knife

REMOVING THE ANVILS

The chipper features both a vertical and horizontal anvil. To remove the anvils, open the fastening bolts (A) and (B) (M16). The horizontal anvil fastening bolt (B) is located below the feed opening. Fig. 23.




Fig. 23. Anvil fastening bolts

SHARPENING THE ANVILS

If you notice wear or rounding of the inner edge of the anvil, sharpen the anvils so that the original angles are retained. Fig. 24.




Fig. 24. Anvil profiles

INSTALLING THE KNIVES AND ANVILS

- Check the condition of the fastening bolts and nuts.
- Install the knives and anvils and tighten the fastening bolts to the torques specified in table.
- Adjust the knife-to-anvil clearance.

ADJUSTING THE KNIFE-TO-ANVIL CLEARANCE

The need for adjusting the anvils is determined by the amount the knives are sharpened. Always check and, if necessary, adjust the clearance between knives and anvils

- after a heavy sharpening;
- if the knives were removed - for example, due to sharpening;
- if new knives are replaced.

Check the clearance with a feeler gauge.

1. Loosen the anvil fastening bolts (A) and (B) (M16). Fig. 23.
2. Turn the disk so that a knife and the anvil are aligned. Place a feeler gauge between the knife and anvil. Adjust the vertical anvil clearance with the adjusting nuts (M12) (C, Fig. 25.) to 1.2–1.5 mm (0.05–0.06").
3. Tighten the adjusting nuts (C) and anvil fastening bolts (A).
4. Adjust the horizontal anvil clearance at the front edge to 4–5 mm (0.16 – 0.20").
5. Tighten the fastening bolt (B).
6. Re-check the knife-to-anvil clearances.




Fig. 25. Vertical anvil fastening and adjustment

CH160




Fig. 26. Cross-section of the disk and knives / anvils

REPLACING THE SPLINED SHAFT

1. Remove the upper chamber.
2. Remove the bearings (see Chapter 13).
Welding damages the bearings.
3. Lift the disk up using a hoist.
4. Grind an 11-mm-deep groove about 17 mm from the edge of the shaft. See Fig. 27.
5. Heat the joint area, if necessary.
6. Move the splined shaft so that it comes loose and can be removed.
7. Clean the shaft hole and install the new shaft as shown in Fig. 27..
8. Make a fillet weld up to the surface level with three runs. Use ESAB 68.81, OK 48, OK Femax 38.65, or equivalent filler.




Fig. 27. Replacing the splined shaft

REPLACING THE BEARING

1. Open the upper chamber. See Section Opening and removing the upper chamber.
2. Remove the fastening bolts M10 (7) and the upper bearing housings (6).
3. Mark the location of the tightening cone on the shaft.
4. Lift the disk.
5. Bend the claw of the securing ring (3) out from the notch on the axle nut and open the axle nut.
6. Remove the axle nut, securing ring, spacer ring (4), bearing (5), spacer ring (9), and tightening cone (10).
7. Install the tightening cone, spacer ring (9), and bearing on the disk shaft. Note the thickness of the spacer ring (9) - see Fig. 28.
8. Install the securing ring with the claws facing outwards and the inside claw in the groove of the tightening cone, and install the axle nut.
9. The inner ring of the bearing should press tightly against the tightening cone.
10. Tighten the axle nut with a hook spanner until the bearing is tightly on the cone, or to 80 Nm. However, the outer ring of the bearing should turn freely. Note the location of the tightening cone on the shaft.
11. Bend one claw of the securing ring (3) into a notch on the axle nut.
12. Install the other half of the dust cover and end plate on the bearing housing. Install the spacer ring (4) on the shaft.
13. Lower the disk to the bearing housing.
14. Attach the other half of the dust cover to the upper bearing housing; install the upper bearing housing fastening bolts and tighten to 50 Nm.
15. Lubricate the bearing housing. An excessive amount of grease causes overheating and impairs lubrication.




Fig. 28. Bearing, feeder side




Fig. 29. Bearing, splined shaft side

The bearings at the feeder side and splined shaft side are different from each other. The bearing at the splined shaft side, Fig. 29., does not have spacer rings (4 and 9) and an end plate (1). The bearing at the splined shaft side has dust covers on both sides (11).

ADJUSTING THE BEARING CLEARANCE

1. Open the upper chamber. See Section Opening and removing the upper chamber.
2. Remove the fastening bolts (M10) (7) and the upper bearing housings (6).
3. Remove the grease from the bearing housing.
4. Lift the disk.
5. Bend the claw of the securing ring (3) out from the notch on the axle nut and open the axle nut.
6. Remove the spacer ring (3) if the bearing is at the feeder side.
7. Measure the radial clearance on top of the bearing between the rollers and outer ring with a feeler gauge. The clearance should be 0.02–0.03 mm (0,008-0,012"). Measure the clearance by pushing the feeler gauge between the rollers (point A, Fig. 31.) through the bearing and then moving the gauge back and forth between the rollers and outer ring - see Fig. 32. Do not force the feeler gauge through the clearance.
8. If the clearance exceeds 0.03mm, bend the claw of the securing ring (2) out from the notch on the axle nut (1).
9. The bearing is tightened by turning the axle nut clockwise with a 70 mm (2 3/4") hook spanner until the right clearance is achieved. Do not tighten by hammering the axle nut.
10. Turn the axle nut clockwise until the notch is aligned with the nearest claw of the securing ring. Bend the claw into the notch. Do not bend the claw that was bent earlier.
11. Lower the disk to the bearing housing.
12. Install the upper bearing housing and tighten the bolts (6) to 50 Nm (36 7/8 lbf).
13. Lubricate the bearing housing. An excessive amount of grease causes overheating and impairs lubrication.




Fig. 30. Bearing, feeder side




Fig. 31. Push the feeler gauge between the rollers and outer ring.




Fig. 32. Measuring the clearance





Fig. 33. Tightening the bearing

CH160


DISCHARGE PIPE



| Part | Order no | Description | Remarks | Qty |
|------|----------|----------------------|-----------------|-----|
| | 03515310 | Short discharge pipe | complete | |
| | 03515320 | Long discharge pipe | complete | |
| 1 | 43514600 | Short discharge pipe | | 1 |
| 2 | 43510240 | Lid | | 1 |
| 3 | 52117108 | Lock nut | M10 DIN985 88ZN | 4 |
| 4 | 03510300 | Chain | 600 | 1 |
| 5 | 94612082 | Tension spring | DU26 DL2,6 L106 | 1 |
| 6 | 43340769 | Butterfly nut | | 1 |
| 7 | 43511670 | Safety screw | M16X40 | 1 |
| 8 | 52840295 | Cotter pin | 5X24 DIN1481 | 3 |
| 9 | 43340751 | Reel | | 2 |
| 10 | 52117082 | Lock nut | M8 DIN985 88ZN | 1 |
| 11 | 43511650 | Safety screw | M10X50 | 2 |
| 12 | 52200334 | Washer | M8 DIN440 ZN | 1 |
| 13 | 43514610 | Long discharge pipe | | 1 |
| 14 | 03514590 | Chain | 1100 | 1 |

CH160

CH160




CH160

CH160

| Part | Order no | Description | Remarks | Qty |
|------|----------|------------------|--------------------|-----|
| 1 | 33514290 | Lower housing | | 1 |
| 2 | 03510200 | Disc | complete | 1 |
| 2.1 | 33510190 | Disc | | 1 |
| 2.2 | 43510220 | Knife | | 2 |
| 2.3 | 52060258 | Screw | M10X40 DIN933 88ZN | 8 |
| 2.4 | 52117108 | Lock nut | M10 DIN985 8ZN | 8 |
| 3 | | Bearing system | | |
| 4 | 43511630 | Safety screw | | 2 |
| 5 | 43513140 | Extension plate | mounting | 1 |
| 5.1 | 43512490 | Extension plate | | 1 |
| 5.2 | 52062023 | Screw | M12X30 DIN933 88ZN | 1 |
| 5.3 | 52200508 | Washer | M12 DIN440 ZN | 2 |
| 5.4 | 52117124 | Lock nut | M12 DIN985 8ZN | 1 |
| 6 | 43341270 | Mounting plate | | 2 |
| 7 | 52117165 | Lock nut | M16 DIN985 8ZN | 1 |
| 8 | 43511660 | Safety screw | M16X240 | 1 |
| 9 | 52062056 | Screw | M12X60 DIN931 88ZN | 4 |
| 10 | 41215682 | Washer | | 4 |
| 11 | 52117124 | Lock nut | M12 DIN985 88ZN | 7 |
| 12 | 52062916 | Screw | M16X60 DIN933 88ZN | 1 |
| 13 | 52110079 | Nut | M16 DIN934 8ZN | 1 |
| 14 | 43510420 | Splined shaft | | 1 |
| 15 | 52060043 | Screw | M6X25 DIN933 88ZN | 5 |
| 16 | 43511630 | Safety screw | M12X50 | 2 |
| 17 | 33345150 | Upper housing | | 1 |
| 18 | 52062031 | Screw | M12X40 DIN933 88ZN | 2 |
| 19 | 43340546 | Screw | L202 | 1 |
| 20 | 33341009 | Vertical anvil | | 1 |
| 21 | 33340993 | Horizontal anvil | | 1 |
| 22 | 52117066 | Lock nut | M6 DIN985 88ZN | 5 |
| 23 | 52842143 | Cotter | 5X105 | 1 |
| 24 | 43291103 | Anvil adjuster | | 2 |
| 25 | 52110053 | Nut | M12 DIN934 8ZN | 8 |
| 26 | 52062106 | Screw | M16X30 DIN933 88ZN | 2 |
| 27 | 52062098 | Screw | M16X25 DIN933 88ZN | 1 |
| 28 | 43341429 | Locking pin | | 1 |
| 29 | 52211042 | Spring washer | M10 DIN127 ZN | 1 |
| 30 | 03291143 | Chain | | 1 |
| 31 | 52832045 | Rivet | 4,8X19 | 2 |
| 32 | 43310499 | Washer | | 1 |
| 33 | 52060209 | Screw | M10X16 DIN933 88ZN | 1 |

CH160

03514390 BELT TRANSMISSION CH160T $i=2,1$




CH160

03514390 BELT TRANSMISSION CH160T i=2,1

| Part | Order no | Description | Remarks | Qty |
|------|----------|------------------------------|---------------------|-----|
| 1 | 43514300 | Belt pulley | D315 | 1 |
| 2 | 43514450 | Bearing housing | | 1 |
| 3 | 43514330 | Belt pulley | complete | 1 |
| 3.1 | 43514350 | Belt pulley | D150 | 1 |
| 3.2 | 43514340 | Tapered adapter sleeve | | 1 |
| 3.3 | 52214269 | Lock washer | M12 NORD-LOCK | 3 |
| 3.4 | 52062023 | Screw | M12X30 DIN933 88ZN | 3 |
| 4 | 54822382 | Belt | | 5 |
| 5 | 43512020 | Belt tightener | complete | 1 |
| 5.1 | 43512030 | Belt tightener | | 1 |
| 5.2 | 43341106 | Reel | | 1 |
| 5.3 | 52840055 | Cotter pin | 5X50 DIN1481 | 1 |
| 5.4 | 43341114 | Pin | | 1 |
| 5.5 | 54511134 | Slotted sealed ball bearing | | 2 |
| 6 | 43341114 | Pin | | 1 |
| 7 | 52063658 | Screw | M12x120 DIN933 88ZN | 1 |
| 8 | 43511950 | Pin | | 1 |
| 9 | 43512050 | Adjusting plate | | 1 |
| 10 | 52090560 | Screw | M12x50 DIN933 10.9 | 4 |
| 11 | 52117124 | Lock nut | M12 DIN985 8ZN | 4 |
| 12 | 43511970 | Cover plate | | 1 |
| 13 | 43511780 | Cover of the universal shaft | | 1 |
| 14 | 52060126 | Screw | M8X20 DIN933 88ZN | 6 |
| 15 | 52117082 | Lock nut | M8 DIN985 8ZN | 6 |
| 16 | 43402150 | Spring | | 1 |
| 17 | 54512140 | Ball bearing | | 2 |
| 18 | 52230257 | Circlip | 45x2,5 DIN471 | 1 |
| 19 | 52200466 | Washer | M12 DIN440 ZN | 4 |
| 20 | 52200334 | Washer | M8 DIN440 ZN | 2 |
| 21 | 52200037 | Washer | M8 DIN126 58ZN | 6 |
| 22 | 52840055 | Cotter pin | 5X50 DIN1481 | 2 |

CH160


BEARING SYSTEM



| Part | Order no | Description | Remarks | Qty |
|------|----------|----------------------------|--------------------|-----|
| 1 | 54513569 | End plate | | 1 |
| 2 | 54512371 | Tightener sleeve, complete | | 2 |
| 2.1 | - | Axle nut | | 1 |
| 2.2 | - | Locking plate | | 1 |
| 2.3 | - | Tightener sleeve | | 1 |
| 3 | 43513360 | Spacer ring | D90/83X12.7 | 1 |
| 4 | 54512363 | Tapered roller bearing | | 2 |
| 5 | 54513590 | Bearing housing | | 2 |
| 5.1 | 52401015 | Grease nipple | AR1/8 | 1 |
| 5.2 | - | Screw | M10x50 DIN931 10.9 | 2 |
| 6 | 43513350 | Spacer ring | D90/83X5.4 | 1 |
| 7 | 52334232 | Seal | | 1 |

CH160




MOUNTING FRAME



| Part | Order no | Description | Remarks | Qty |
|------|----------|------------------------------|--------------------|-----|
| 1 | 43343790 | Draw bar | | 1 |
| 2 | 52062221 | Screw | M20X50 DIN933 88ZN | 4 |
| 3 | 52117207 | Lock nut | M20 DIN985 8ZN | 4 |
| 4 | 52211083 | Spring washer | M20 DIN127 ZN | 4 |
| 5 | 40293797 | Bushing | | 2 |
| 6 | 52842150 | Ring cotter | 10X45 | 2 |
| 7 | 52832094 | Rivet | 4,8X15 FE | 2 |
| 8 | 54826110 | Chain | | 2 |
| 9 | 52060175 | Screw | M8X25 DIN933 88ZN | 10 |
| 10 | 43482290 | Hose fastener | | 1 |
| 11 | 52200037 | Washer | M8 DIN126 58ZN | 10 |
| 12 | 52117082 | Lock nut | M8 DIN985 88ZN | 10 |
| 13 | 43514240 | Cover plate | | 1 |
| 14 | 43514210 | Cover plate | | 1 |
| 15 | 43511780 | Cover of the universal shaft | | 1 |
| 16 | 52200334 | Washer | M8 DIN440 ZN | 2 |

CH160

03511030 FEED CHUTE F160






CH160

03511030 FEED CHUTE F160

| Part | Order no | Description | Remarks | Qty |
|------|----------|----------------------------|---------------------|-----|
| 1 | 43517400 | Feed chute | F160 | 1 |
| 2 | 43517640 | Safety clapper | | 1 |
| 3 | 43517690 | Safety clapper | PVC | 1 |
| 4 | 94613098 | Tension spring | DU23 DL3,5 L200 | 1 |
| 5 | 52070406 | Screw | M8x35 DIN931 88ZN | 2 |
| 6 | 52060233 | Screw | M10X30 DIN933 88ZN | 3 |
| 7 | 52060191 | Screw | M8X22 DIN933 88ZN | 3 |
| 8 | 43517710 | Bracket | | 1 |
| 9 | 52117082 | Lock nut | M8 DIN985 8ZN | 5 |
| 10 | 52117108 | Lock nut | M10 DIN985 8ZN | 3 |
| 11 | 52063013 | Screw | M16X240 DIN931 88ZN | 1 |
| 12 | 52117165 | Lock nut | M16 DIN985 8ZN | 1 |
| 13 | 43517730 | Support for transportation | | 1 |
| 14 | 43517630 | Safety handle | | 1 |
| 15 | 43517650 | Spring release lever | | 1 |
| 16 | 43517590 | Safety clapper axle | | 1 |

CH160

LÖSI EPMS 100 C




CH160

56001589 LÖSI EPMS 100 C

| Part | Order no | Description | Remarks | Qty |
|------|----------|------------------------|----------|-----|
| 1 | 58005299 | Axle cover | | 1 |
| 2 | 58005307 | Axle | | 1 |
| 3 | 58005315 | Key | | 1 |
| 4 | 58005323 | Seal ring | | 1 |
| 5 | 58005331 | Seal | | 1 |
| 6 | 58005349 | Housing | | 1 |
| 7 | 58005356 | Tapered roller bearing | | 2 |
| 8 | 58005364 | Bearing | | 1 |
| 9 | 58005372 | Lock nut | M40X1,5 | 1 |
| 10 | 58005380 | Plug | G1/4"-A | 1 |
| 11 | 58005398 | Washer | 13X17 | 1 |
| 12 | 58005406 | Sprocket kit | | 1 |
| 13 | 58005414 | Pin | | 1 |
| 14 | 58005422 | Spring washer | | 1 |
| 15 | 58005430 | Seal plug | | 2 |
| 16 | 58005448 | Flange | | 1 |
| 17 | 58005455 | Pin | | 1 |
| 18 | 58005463 | O-ring | | 1 |
| 19 | 58005471 | Label | | 1 |
| 20 | 58005489 | Rivet | 2X5 | 4 |
| 21 | 58005497 | Screw | M10X130 | 4 |
| 22 | 58005505 | Washer | | 1 |
| 23 | 58005513 | Plate | | 1 |
| 24 | 58005521 | O-ring | | 1 |
| 25 | 58005539 | Valve plate | | 1 |
| 26 | 58005547 | Valve guide | | 1 |
| 27 | 58005554 | Plate | | 1 |
| 28 | 58005562 | O-ring | | 2 |
| 29 | 58005570 | Seal ring | | 1 |
| 30 | 58005588 | Plate | | 1 |
| 31 | 58005596 | O-ring | | 1 |
| 32 | 58005604 | Propeller shaft | | 1 |
| 33 | 58005612 | Plug | M10X1 | 2 |
| 34 | 58005620 | Washer | A10X14 | 2 |
| 35 | 58005638 | Spring | | 2 |
| 36 | 58005646 | Guide pin | | 2 |
| 37 | 58005653 | Ball | | 2 |
| 38 | 58005661 | Plug | G-1/2"-A | 2 |
| 39 | 58005679 | Washer | 22X27-Cu | 2 |

CH160


HD100



| Part | Order no | Description | Remarks | Qty |
|------|----------|------------------------|--------------------|-----|
| 1 | 56001589 | Hydraulic motor | LÖSI EPMS 100 C | 1 |
| 2 | 52432044 | Double fitting | R1/2-3/4" | 2 |
| 3 | 56533151 | Hose assy | V3/4"S L=1,0 m | 2 |
| 4 | 52390580 | Usit-ring | U27,05X34,93X2,49 | 2 |
| 5 | 52449220 | Quick fitting | 3/4" SK | 2 |
| 6 | 52449238 | Quick fitting coupling | 3/4" SK | 2 |
| 7 | 52062031 | Screw | M12X40 DIN933 88ZN | 4 |
| 8 | 52062023 | Screw | M12X30 DIN933 88ZN | 2 |
| 9 | 52117124 | Lock nut | M12 DIN985 8ZN | 14 |
| 10 | 54923073 | Damper | | 2 |
| 11 | 43510640 | Motor support | | 1 |
| 12 | 43510620 | Fastener | left | 1 |
| 13 | 43510630 | Fastener | right | 1 |
| 14 | 43510590 | Coupling sleeve | | 1 |
| 15 | 43510540 | Limiter plate | | 1 |
| 16 | 56053986 | Inlet valve | R1/2" | 1 |
| 17 | 52301397 | O-ring | 21,95x1,78 90SH | 2 |
| 18 | 52060225 | Screw | M10X25 DIN933 88ZN | 1 |
| 19 | 52117108 | Lock nut | M10 DIN985 88ZN | 5 |

CH160


ADAPTER WILLE



| Part | Order no | Description | Remarks | Qty |
|------|----------|---------------|---------------------|-----|
| | 43510500 | Adapter Wille | complete | |
| 1 | 43510490 | Frame | | 1 |
| 2 | 43510510 | Plate | | 2 |
| 3 | 52062163 | Screw | M16X100 DIN931 88ZN | 4 |
| 4 | 52117165 | Lock nut | M16 DIN985 88ZN | 4 |
| 5 | 52200078 | Washer | M16 DIN126 58ZN | 4 |
| 6 | 43512510 | Screw | M20X120 | 1 |
| 7 | 52117207 | Lock nut | M20 DIN985 88ZN | 1 |

CH160

ADAPTER BOBCAT



| Part | Order no | Description | Remarks | Qty |
|------|----------|-----------------|--------------------|-----|
| 1 | 03510800 | Adapter frame | | 1 |
| 1.1 | 43510820 | Upper beam | | 1 |
| 1.2 | 43510830 | Fastener | left | 1 |
| 1.3 | 43510840 | Fastener | right | 1 |
| 1.4 | 52062023 | Screw | M12X30 DIN933 88ZN | 4 |
| 1.5 | 52117124 | Lock nut | M12 DIN985 88ZN | 8 |
| 1.6 | 43512510 | Screw | 20X120 | 1 |
| 1.7 | 43513120 | Fastening plate | | 1 |
| 1.8 | 52200466 | Washer | M12 DIN440 ZN | 8 |
| 1.9 | 52117207 | Lock nut | M20 DIN985 88ZN | 1 |
| 2 | 52062221 | Screw | M20X50 DIN933 88ZN | 2 |
| 3 | 52211083 | Spring washer | M20 DIN127 ZN | 4 |
| 4 | 52117207 | Lock nut | M20 DIN985 88ZN | 4 |
| 5 | 52062213 | Screw | M20X40 DIN933 88ZN | 2 |

WARRANTY

Farmi Forest Oy grants a 12-month warranty on all of its products, covering material and manufacturing faults. The warranty comes into effect on the product's delivery date.


The manufacturer is not liable for damages caused by:

- misuse of the product
- alterations or repairs made without the manufacturer's permission
- insufficient maintenance
- non-original parts


The warranty does not cover wearing parts.

Send faulty parts, carriage paid, to the manufacturer for inspection. Repairs will be conducted by Farmi Forest Oy or an authorized expert. The warranty is valid only if the bottom part of this page is filled in and returned to the manufacturer within 14 days of receipt of the product.

By returning the warranty certificate, you confirm that you have read and understood the instruction manual that came with the product.



Farmi Forest Corporation
Ahmolantie 6
FIN-74510 IISALMI
FINLAND



Date of delivery:____/____ 20____

Dealer:_____

Dealer’s address:_____

Dealer’s tel:_____

Product and type:_____

Serial number:_____



Return to the manufacturer

-----|

Date of delivery:____/____ 20____

Dealer:_____

Dealer’s address:_____

Dealer’s tel:_____

Customer:_____

Customer’s address:_____

Customer’s tel:_____

Product and type:_____

Serial number:_____



FARMIForest

Farmi Forest Corporation
Ahmolantie 6
FIN-74510 Iisalmi, Finland
Puh. +358 (0)17 83 241
Fax. +358 (0)17 8324 372
www.farmiforest.fi